

## RECOMMENDED ADHESIVES AND NAP SIZES: VITRULAN GLASS TEXTILE & VRP® INSTALLATIONS

The following are recommended adhesives and nap sizes for for installation of Vitrulan Glass Deco Textile Wallcoverings with the VRP Wall System.

## Adhesives:

The following are recommended adhesives for installation of our Glass Deco Textile Wallcoverings for the VRP Wall System.

- All adhesives are readily available at retail outlets of all major paint manufacturers, independent paint stores as well as "big box" retailers.
- All recommended adhesives are commercial grade, heavy duty, clear and can be rolled on or used with pasting machines.
- All substrates should be primed with a commercial grade primer prior to application of adhesives.

Adhesive Product Data and Safety Sheets are readily available on each manufacturer's web-site.

MANUFACTURER	PRODUCT	WEBSITE
Roman Adhesives	PRO-880 PRO-888 (environmental) PRO-838	www.romandecoratingproducts.com
Zinsser	Sure Grip 128 Sure Grip 122	www.zinsser.com

## **Roller Naps:**

The following are recommended roller nap sizes for rolling adhesive on the wall when 'dry hanging' Vitrulan Glass Textile fabrics, and to roll on our coatings and paint on all textile styles.

## Only quality rollers should be used

All adhesives use nap size	1/2 "or 5/8"
'PlusCoat' 200 and latex paints use nap size	1/2" or 5/8"
'PlusCoat' - 400 Gloss, 500 Satin, or 600 Matte use nap size	1/4" or 3/16"

888-267-4067 vitrulanusa.com