

SURFACE PREPARATION

INSTALLING VITRULAN® GLASS DECO FABRIC OVER GLASS BLOCK WALL / CINDER BLOCK (CMU)

SURFACE PREPERATION

- 1. Clean and degrease all ceramic, glass or painted tile surface with appropriate commercial cleanser.
- 2. Apply appropriate bonding agent, such as Zinsser Bondz[®].
- **3.** Fill and smooth surface with drywall compound to a level two (2) finish, filling in all joints of the complete surface.
- **4.** Fill transition seams or gaps with drywall compound.
- **5.** Embed drywall tape over seam or gap between drywall and glass block transition. Finish with drywall compound to achieve smooth and flat transition from glass/tiles surface to extension wall.
- **6.** Prime surface with quality primer/sealer.

INSTALLATION OVER TRANSITION SEAM

- 1. After surface has thoroughly dried, install Vitrulan® Glass Deco Textile according to instructions.
- 2. To achieve maximum coverage and appropriate installation over transitions seams make certain that Vitrulan Glass Deco Textile seams are at least twelve (12) inches from glass/drywall transition seam, or gap on either side.
 - a. As base product is flexible textile, seams will "telegraph" if not covered properly.







Covered Glass Tile